



NORTH  
AMERICAN  
POLYMER  
COMPANY

NAPCO

## NAPCO INLAY INSTALLATION INSTRUCTIONS

### Inlay Kit Includes:

- Inlay
- Adhesive with screw-on nozzle (for capping after use)
- Disposable gloves – 1 pair
- Plastic notched spreader

### Other Material Needed for Installation:

- Rubber Roller (optional)
- Sponge
- Soft scrub brush
- Pencil
- NAPCO Poly-Cleaner
- Isopropyl Alcohol
- 80 grit wet/dry sandpaper
- Acid gas cartridge respirator mask
- Goggles
- Drop cloths
- Roll of paper towels
- Garbage bag
- Empty plastic gallon jugs
- NAPCO Froth Pak\* (when needed)
- Drill (if using Froth Pak)

### Inlay Kit Includes:

1. Dry fit the tub/shower inlay first to ensure a good fit.
2. Cover the floor, toilet seat, etc. with drop cloths to ensure that you do not get adhesive on anything in the room.
3. Thoroughly clean the tub/shower bottom with NAPCO Poly-Cleaner, a sponge and water. For textured bottoms, use a soft scrub brush to clean into the texture.
4. Rinse the tub/shower well and dry the tub/shower bottom completely.
5. Lay the tub/shower inlay in place and make sure it is straight and centered. With a pencil, lightly trace the outline of the inlay onto the tub/shower bottom. Remove the inlay.
6. When installing inlay onto a previously refinished tub or shower bottom, the existing coating must be adhering well to the original fixture. If the coating is peeling or flaking, it must be stripped off to ensure a good bond with the inlay.
7. Wet sand the damaged bottom up to the pencil line with 80 wet/dry sandpaper. Sand inside the pencil line only. (For porcelain and ceramic use etch and sand)
8. Dry the tub/shower bottom and inspect. The surface must be clean, dry, sanded, and dust-free. Sand the under-side of inlay (smooth side) with 80 grit. Clean under-side with isopropyl to remove any sanding dust.
9. Wear a respirator mask, gloves, and goggles when working with the adhesive.
10. To open the caulk tube, slice off the tip of the nozzle just below the first thread with a razor blade. Be sure to leave the threads intact so that you can screw the nozzle on later for storage. DO NOT use the nozzle for dispensing, because the adhesive is too thick and the adhesive will be very difficult to dispense.



NORTH  
AMERICAN  
POLYMER  
COMPANY

11. Apply a bead of adhesive around the perimeter of the tub/shower bottom, staying  $\frac{1}{4}$ " inside the pencil line. Apply a 2nd bead of adhesive 1-1/4" inside the pencil line. Then apply beads of adhesive horizontally (side to side/shortest distance) every 3" throughout the length of the tub/shower bottom.
12. Drag the plastic notched spreader through the lines of adhesive, spreading adhesive evenly over the entire outlined area of the tub/shower bottom. Spread adhesive right up to the pencil line.
13. Place the inlay sanded side down onto the outlined area of the tub/shower bottom.
14. Stand up and make sure the inlay looks straight. If not, adjust it by sliding the inlay into position and push down firmly on the surface of the inlay.
15. Use a rubber roller (or your hand) to roll or push from the center of the inlay out to the edges, forcing out any air bubbles or excess adhesive. **Note: You must have adhesive coming out all the way around the inlay to assure that the inlay will completely seal itself to the tub/shower bottom and have good adhesion. If there is an area where adhesive is not coming out, lightly lift that area of the inlay with your fingers and use the spreader to apply some of the excess adhesive under the edge of the inlay.**
16. Slide the plastic spreader forward like a mini snow shovel around the edges of the inlay, scooping up excess adhesive. Frequently wipe excess adhesive off the spreader using a paper towel moistened with isopropyl alcohol. Dispose of excess adhesive and paper towels in a plastic garbage bag. **Note: Be very careful not to get adhesive on anything else in the bathroom (floor, toilet seat, etc.).**
17. Dampen paper towels with isopropyl alcohol and wipe along the edges of the inlay to remove the remaining thin layer of adhesive. Dispose of the paper towels in the garbage bag as they get dirty. Use plenty of fresh damp paper towels.
18. Inspect the job. Once you have finished removing the excess adhesive, the job is complete.
19. Wait 24 hours before showering and 48 hours before taking a bath.
20. Whenever possible, weigh the inlay down at the edges to ensure the best possible bond. We recommend filling empty gallon milk or water containers with water and placing them at the corners of the inlay. The customer can dispose of them the next day.

*\*When the tub/shower bottom is excessively cracked or soft, use a NAPCO Froth Pak prior to installing the inlay. Call NAPCO toll-free at 1-800-888-1081 for Froth Pak pricing and application instructions.*



NORTH  
AMERICAN  
POLYMER  
COMPANY

NAPCO

## NAPCO INLAY INSTRUCCIONES DE INSTALACION

### Kit de Inlay Incluye:

- Inlay
- Adhesivo con tapadera de tornillo en la boquilla ( para tapar después de uso)
- Guantes Desechables – Un Par
- Espátula de plástico

### Otros materiales necesarios para instalación:

- Rodillo (opcional)
- Esponja
- Cepillo suave
- Lápiz
- Producto de limpieza abrasivo (fuerte)
- Alcohol 99% puro
- Papel de lija húmedo/seco Grano #80
- Lona
- Rollo de toallas de papel
- Bolsa para la basura
- Garrafrones de plástico vacios (galón)
- Espuma e aerosol (dos partes) Solamente cuando sea necesario
- Taladro (si está usando la espuma)

### Instrucciones de Instalación:

1. Coloque el inlay adentro de la tina sin adhesivo para asegurar que su inlay quede apropiadamente.
2. Cubra el piso, asiento de inodoro con una lona para evitar que se llene de adhesivo la habitación.
3. Limpiar a fondo la parte inferior de la bañera/ducha con un limpiador abrasivo, esponja y agua. Para el fondo de textura, use un cepillo suave para limpiar en la textura.
4. Enjuague la tina generosamente con agua y secar completamente. Que no quede mojada la tina.
5. Sin adhesivo coloque el inlay para asegurar que este centrado el inlay. Cora un lápiz al rededor del inlay enzima de la tina y remueva el inlay.
6. Al instalar el inlay en una tina que ha sido anteriormente re acabado la superficie existente debe adherirse bien a la fijación original. Si la capa se está pelando debe ser despojado de asegurar una buena adherencia con la incrustación.
7. Lije la parte dañada hasta la línea de lápiz con la húmeda/seca #80. Solamente lijando adentro de la línea de lápiz.
8. Seque la parte interior de la bañera. La superficie debe estar limpia, seca, lijada y libre de polvo. La arena de la cara inferior de la incrustación (lado liso) de 80 granos.
9. Retire la lengüeta de parte inferior del tubo. Agujere la parte superior del tubo para abrir. No use la boquilla para dispensar, porque el adhesivo es demasiado grueso y será muy difícil de dispensar. Coloque el tubo en una pistola de calafateo estándar.
10. Aplique un cordón de adhesivo alrededor de la parte inferior de la bañera, alojarse ¼”



NORTH  
AMERICAN  
POLYMER  
COMPANY

NAPCO

dentro de la línea de lápiz. Aplique una segunda tira de 1 ¼" dentro de la línea de lápiz. Luego se aplican gotas de adhesivo horizontal (de lado a lado/distancia más corta) cada 3" a lo largo de la longitud de la parte inferior de la bañera.

11. Arrastre la espátula de plástico a través de las líneas de adhesivo, extendiendo adhesivo uniformemente sobre toda el área de la parte inferior de la bañera. Extienda el adhesivo hasta la línea de lápiz.
12. Coloque el infla lado liso hacia abajo sobre el área marcada de la tina.
13. Ponerse de pie y asegurarse de que el inlay este puesto correctamente. Si no, ajuste por deslizamiento el inlay en su posición y empuje hacia abajo firmemente en la superficie del inlay.
14. Usar un rodillo de goma (o la mano) para rodar o empujar desde el centro de el inlay hasta los bordes, lo que obliga a las burbujas de aire o el exceso de adhesivo. **Nota: Debe de haber adhesivo que sale todo el camino alrededor de el inlay con el fin de garantizar que el inlay este completamente sellado en la parte inferior de la tina y tener una buena adherencia. Si hay un ámbito en el adhesivo no está saliendo levante lajeramente el área del inlay con los dedos y usar la espátula para aplicar el exceso de adhesivo en el borde del inlay.**
15. Deslice la espátula de plástico hacia adelante como una pala de nieve mini-alrededor de los bordes del inlay, recogiendo el exceso de adhesivo. Frecuentemente limpie con una toalla de papel humedecido con alcohol. Elimine el exceso de adhesivo y toallas de papel en una bolsa de basura de plástico. **Nota: Tenga mucho cuidado de no llenar de adhesivo en ningún otra cosa en el cuarto de baño.**
16. Humedezca toallas de papel con alcohol y limpie a lo largo de los bordes del inlay para eliminar la capa delgada de adhesivo restante. Deseche las toallas de papel en la bolsa de basura, ya que se ensucian. Siempre use nuevas toallas de papel húmedas para cada trabajo nuevo.
17. Inspeccione el trabajo. Una vez que haya terminado de quitar el exceso de adhesivo, el trabajo esta completo.
18. Espere 24 horas a 73 grados F y 50% de humedad relativa, antes de vanarse.
19. Siempre que sea posible se recomienda llenar galones de leche con agua y colocarlos en las esquinas del inlay. El cliente puede disponer de ellos al día siguiente.

*\* Cuando el fondo de la bañera este demasiado agrietado o suave, use un espray de espuma de dos componentes antes de instalar el inlay. Llame a NAPCO al número gratuito 1-800-888-1081 para precios e instrucciones.*